



INSTALLATION INSTRUCTIONS & PART DIAGRAM

Compact Hardware



JAMB MUST BE SQUARE AND PLUMB
A MINIMUM OF 3-1/2 INCH WIDE JAMBS
REQUIRED TO MOUNT HARDWARE



1. Measure width and height of framed opening and compare width dimensions given at time of ordering. (This model was cut to the dimensions given by the customer and is not adaptable to fit into a different size opening.)
2. Position bottom pin assembly in desired location of floor and center on side jamb. Secure to jamb using four 1-1/2" screws supplied.
3. Locate top pin assembly by using height of the door + 1-1/2". This dimension is from the bottom of the bottom pin assembly to the top of the top pin assembly. Secure top pin assembly to side jamb using four 1-1/2" screws supplied.
4. Slip door over bottom pin and lift slightly to slide door pod over bearing plate. Line up holes and insert bolts supplied. Partially install lock nuts, move door to closed position and secure lock nuts.
5. Install covers and secure four 1/2" screws supplied per door.

Top Pin Assy

- (4) 1/4" - 20 x 1" phil. flt hd. thread cutting screws
- (4) #14 - 1-1/2" phil. flt hd. sheet metal / wood screws

- Bearing Plate with (2) 5/16 - 18 screws, (2) 5/16 - 18 lock nuts

- 3/8" Axle

- (2) Rollers

- (2) Kliprings

(LH/RH) - (2) Aluminum Covers, (4) screws

(LH/RH) - (2) SS Covers, (4) screws

(LH/RH) - (2) ABS Covers, (4) screws

- Bottom Pin Assy (4) of each fastener listed under

- Bottom Pin Bushing (LW Model only)

